

Auto Crete Form A Drain

Drawing

1. Drawing Walls using Definition
2. Trace Over Drawing
3. Two Wall line Drawing
4. Draw Footings with Wall Line.
5. Wall Drawing Using Xdata
6. Convert Vector PDF's to DXF/DWG Files
7. Paste Snap shot of Raster Image PDF.
8. Place Grid Lines
9. Place Title Block
10. Place Dimensions while Drawing

Pro Form HD Footing Forming

1. Pro Form HD Placement (Manual)
2. Count pro Form
3. Single Outlet Adapter
4. End Cap
5. Coupler
6. Crossover Adapter
7. Vertical Elbow
8. Pro Form Layer Get Text
9. Pro Form HD Layer Leader Line
10. Pro Form HD Layer Control
11. Pro Form HD Dimensioning
12. Delete Pro Form HD