Included with Auto Crete Foundation

Draw

Wall Draw

Footing Draw

Pier Pad Placement

Column Placement

Circular Column Placement

Caissons Placement

Attached Columns and Stem Piers

Draw Interior Footings

Retainer Footings

Place Interior Footing Block

Turndowns and Steps

Wall Pilasters

Corner Pilasters

Cub and Guter

PDF Insertion

Title Block

Takeoff

Auto Takeoff's

Manual Takeoffs

Rebar Takeoff and Matt Slabs

Miscellaneous, Sub Contractor, Equipment

Pumping

Excavation

Count Corners

Grading

Wall Square Footage

Water Proofing

Wall Insulation

Brick ledge by Area

Form Oil

Subtract Blockout Concrete

Pour Sequence - Concrete Job Schedule

Total Station

Auto and Manual Points
Extract files - DXF File, TXT, CVS, DAT, PTS and ASC Files
Excavation Layout
Blowup Layout
Footing Layout
Total Station Dimension Layer
Total Station Get Text

Layout

General Layout Survey Points Trace outline for Excavation Layout Dimension Layer Layout Get Text

Foundation

Foundation Dimension Layer Get Arc Dimension **Auto Dimension Quick Block Dimension Anchor Bolt Placement** Beam Ledge Placement Beam Pocket Placement **Blockout Placement** Brickledge Placement **Curb Placement** Door Placement Drain Tile Placement Footing Void Placement All Floor Insulation Placement Perimeter Floor Insulation Placement Wire Mesh Placement Ledger Placement

Masonry Block Placement
Wall Insulation Placement
Wall Vent Placement
Water Line Placement
Water Stop Placement
Wall Wire Mesh Vertical Placement
Weld Plate Placement
Window Placement
Window Well Placement
Radius Window Well Placement
Saw and Key Joint Placement
Sewer Line Placement
Sump Pump Placement
Ufer Wire Placement
Wall get Text Placement

Footing Forming

Form A Drain
Proform HD
EZ Footing Forming
Aluminum Footing Forming
Lumber Footing Forming
Fineline Footing Forming

Tools
Show Wall
Global Wall Direction
Change Pre Defined Number
Add Wall
Change Wall Direction
Inside X Data
Outside X Data
Interior Footing data
Re-Attach Rebar
Remove Rebar
Modify's an Assemblies Data
Trim Footing and Pier Pads

Remove Wall form Takeoff Draw Order Break at Point Wall and Area Hatching Detail Placement 30 and 45 Degree Layout